

Kanäle / Frequenzen
BOS 70-Zentimeter-Band

Kanal	UB	OB	Anmerkung
690	443,6000	448,6000	
691	443,6125	448,6125	
692	443,6250	448,6250	
693	443,6375	448,6375	
694	443,6500	448,6500	
695	443,6625	448,6625	
696	443,6750	448,6750	
697	443,6875	448,6875	
698	443,7000	448,7000	
699	443,7125	448,7125	
700	443,7250	448,7250	
701	443,7375	448,7375	
702	443,7500	448,7500	
703	443,7625	448,7625	
704	443,7750	448,7750	
705	443,7875	448,7875	
706	443,8000	448,8000	
707	443,8125	448,8125	
708	443,8250	448,8250	
709	443,8375	448,8375	
710	443,8500	448,8500	
711	443,8625	448,8625	
712	443,8750	448,8750	
713	443,8875	448,8875	
714	443,9000	448,9000	
715	443,9125	448,9125	
716	443,9250	448,9250	
717	443,9375	448,9375	
718	443,9500	448,9500	
719	443,9625	448,9625	
720	443,9750	448,9750	
721	443,9875	448,9875	
722	444,0000	449,0000	
723	444,0125	449,0125	
724	444,0250	449,0250	
725	444,0375	449,0375	
726	444,0500	449,0500	
727	444,0625	449,0625	
728	444,0750	449,0750	
729	444,0875	449,0875	
730	444,1000	449,1000	
731	444,1125	449,1125	
732	444,1250	449,1250	
733	444,1375	449,1375	
734	444,1500	449,1500	
735	444,1625	449,1625	
736	444,1750	449,1750	
737	444,1875	449,1875	
738	444,2000	449,2000	
739	444,2125	449,2125	
740	444,2250	449,2250	
741	444,2375	449,2375	
742	444,2500	449,2500	
743	444,2625	449,2625	
744	444,2750	449,2750	
745	444,2875	449,2875	
746	444,3000	449,3000	
747	444,3125	449,3125	
748	444,3250	449,3250	

Kanal	UB	OB	Anmerkung
749	444,3375	449,3375	
750	444,3500	449,3500	
751	444,3625	449,3625	
752	444,3750	449,3750	
753	444,3875	449,3875	
754	444,4000	449,4000	
755	444,4125	449,4125	
756	444,4250	449,4250	
757	444,4375	449,4375	
758	444,4500	449,4500	
759	444,4625	449,4625	
760	444,4750	449,4750	
761	444,4875	449,4875	
762	444,5000	449,5000	
763	444,5125	449,5125	
764	444,5250	449,5250	
765	444,5375	449,5375	
766	444,5500	449,5500	
767	444,5625	449,5625	
768	444,5750	449,5750	
769	444,5875	449,5875	
770	444,6000	449,6000	
771	444,6125	449,6125	
772	444,6250	449,6250	
773	444,6375	449,6375	
774	444,6500	449,6500	
775	444,6625	449,6625	
776	444,6750	449,6750	
777	444,6875	449,6875	
778	444,7000	449,7000	
779	444,7125	449,7125	
780	444,7250	449,7250	
781	444,7375	449,7375	
782	444,7500	449,7500	
783	444,7625	449,7625	
784	444,7750	449,7750	
785	444,7875	449,7875	
786	444,8000	449,8000	
787	444,8125	449,8125	
788	444,8250	449,8250	
789	444,8375	449,8375	
790	444,8500	449,8500	
791	444,8625	449,8625	
792	444,8750	449,8750	
793	444,8875	449,8875	
794	444,9000	449,9000	
795	444,9125	449,9125	
796	444,9250	449,9250	
797	444,9375	449,9375	
798	444,9500	449,9500	
799	444,9625	449,9625	

Allgemeine Infos:

UB: 443,6000 – 444,9625 Mhz
 OB: 448,6000 – 449,9625 Mhz
 Ablage: 5 Mhz Raster: 12,5 kHz

Das gesamte 70cm Band dient nur noch als Relaiszubringer des Gleichwellenfunknetzes.